



- 1| Click the handle vertically into the groove
- 2| Click the closing elements vertically into the designed openings
- 3| Insert the fastener vertically and turn anti-clockwise
- 4| Click the handle horizontally into the groove

